




**Attention:** Read and understand these instructions before installing fixture. This fixture is intended for installation in accordance with National Electric Code and local regulation: To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. This equipment is guaranteed only when used as indicated in these instructions; Therefore they should be kept for future reference. To prevent electrical shock, turn off power supply before carrying out any connection or maintenance operations.


Your box should contain the following parts:



Before proceeding with the installation, make sure the frame aperture flange is higher than the ceiling line once installed.

A. Adjust bar bracket by releasing wing nut.


B. Push up or down on mounting brackets and tighten wing nuts.



### STEP 1


#### FOR WOOD JOIST INSTALLATION

- 1.1 Align mounting bar with the bottom edge of the wood joist.
- 1.2 Push on the built-in hook or use wood screws to secure frame.




#### FOR GRID CEILING

- 1.3 Install mounting bar notches on the ceiling T-bar.
- 1.4 Secure mounting bar to grid ceiling with metal wire.



1.5 Lock mounting bars in place by folding bracket tabs.






### STEP 2

**ELECTRICAL CONNECTION**  
2.1 Remove junction box cover.  
2.2 Remove Pry-out knock-out.

2.3 Use BX conduit connector.  
2.4 Make appropriate electrical connection.





ON/OFF VERSION		0-10V DIMMABLE VERSION		DIGITAL VERSION	
FIXTURE WIRES	CEILING WIRES	FIXTURE WIRES	CEILING WIRES	FIXTURE WIRES	CEILING WIRES
BLACK	BLACK	PURPLE +	0-10VDC +	DIGITAL A grey	DIGITAL A
WHITE	WHITE	GREY -	DC -	DIGITAL B purple	DIGITAL B
GREEN	GREEN				

### STEP 3

**CEILING CUT-OUT**  
3.1 Make appropriate ceiling cut-out.

3.2 Adjust mounting frame flush to ceiling by releasing the screws inside the frame.  
3.3 Tighten the screw back inside the frame.



### STEP 4

**DRIVER REPLACEMENT**

4.1 Remove the 2 screws for the driver housing inside the frame  
4.2 Slide the driver housing to the right facing the inside frame section.

4.3 Rotate driver housing inside the frame.  
4.4 Remove driver housing from frame aperture.  
4.5 Remove 4 hex nuts to access inside the driver housing.

