




Attention: Read and understand these instructions before installing fixture. This fixture is intended for installation in accordance with the National Electric Code and local regulation. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. This equipment is guaranteed only when used as indicated in these instructions; therefore they should be kept for future reference. To prevent electrical shock, turn off power supply before carrying out any connection or maintenance operations. During installation, the LED chips may be exposed; please do not touch them to ensure proper long-term operation.


This box should contain :

Round trimless version



AEVH15xRTL-series

Square trimless version




AEVH15xRTL-series

OR

STEP 1

Make appropriate ceiling cut-out.


Everything 150 square trimless



Cut-out :

L 5-3/8" x W 5-3/8" (13,6cm x 13,6cm)

Everything 150 round trimless




Cut-out :

5-3/8" (Ø 13,6cm)



STEP 2


Installation with mounting pan




- 2.1 Push trimless body inside of ceiling aperture.
- 2.2 Install plaster trim using self-tapping drywall screws. (Not provided)
- 2.3 Screws must be intalled through the frame bottom plate.
- 2.4 Cover flange with plaster/ joint compound.
- 2.5 Paint before light engine installation.

2.1


Round trimless version



2.4 Plaster




2.5




2.1

Square trimless version




2.4



Plaster

2.5





STEP 3

For fixed light engine installation


3.1 Make appropriate connections.

Note : For frame installation, refer to frame instruction sheet.


3.2 Close frame connection box cover with light module connection cover.

3.3 Screw frame connection cover and the light module connection cover together (screw provided).

Round trimless version





Square trimless version



STEP 4

For fixed light engine:

Push light engine in trim body and clip together.






STEP 5

For adjustable light engine :
Adjust the rotation ring.

Note : For round version only.



Round trimless version



STEP 6

For adjustable light engine :
6.1 Lock rotation ring with locking screw.

6.2 Make sure to align the larger side of the skirt with the
the larger opening of the trim.


6.3 Push light engine inside trim body.

Round trimless version





Square trimless version




STEP 7

For adjustable light engine :


7.1 Adjust light engine until desired position.

7.2 Lock light engine by twisting screw.



Round trimless version



Adjustable



Square trimless version







STEP 8

Install reflector.

Round trimless version




Square trimless version




For maintenance :
If you need to remove reflector use provided bracket.
Keep bracket for further maintenance.

Round trimless version




Square trimless version





Fixture installed

Round trimless version



Square trimless version

