





Attention: Read and understand these instructions before installing fixture. This fixture is intended for installation in accordance with the National Electric Code and local regulation. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. This equipment is guaranteed only when used as indicated in these instructions; therefore they should be kept for future reference. To prevent electrical shock, turn off power supply before carrying out any connection or maintenance operations. During installation, the LED chips may be exposed; please do not touch them to ensure proper long-term operation.

This box should contain :



STEP 1

- 1.1 Unscrew partially remote driver cover
- 1.2 Open remote driver box cover



STEP 2


- Make appropriate connections
- 2.1 Install BX conduit or Loomex cable using appropriate connector (Not included)
- 2.2 Connect BX conduit with driver wires.
- 2.3 Pass luminaire CMG cable in remote driver strain relief and connect with driver wires.
- 2.4 Close box and screw back

NOTE : For remote driver installation

For series **MSHxx-1** and **MSHxx-2**, remote driver shall not be installed through ceiling aperture. Make sure to connect driver wires from a suitable distance.

For series **MSHxx-4**, **MSHxx-8**, **MSHxx-12** and **MSHxx-16**, remote driver can be installed through ceiling aperture.

LED +		
Red		Remote driver
LED -		
Black		Remote driver



FOR DIGITAL VERSION	
REMOTE DRIVER	CEILING WIRES
GREEN	GREEN
BLACK	PURPLE
WHITE	PURPLE
	DIGITAL
	DIGITAL
FOR 0-10V DIM VERSION	
REMOTE DRIVER	CEILING WIRES
PURPLE	0-10V +
GREY	0-10V -



STEP 3

- 3.1 Connect remote driver CMG cable with luminaire connection box cable. **See step 6 for assembly instructions Sharp trimless luminaire.**
See step 3 for assembly instructions for Sharp trimless luminaire.
3.2 Install luminaire in ceiling aperture

