





*Attention: Read and understand these instructions before installing fixture. This fixture is intended for installation in accordance with National Electric Code and local regulation: To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. This equipment is guaranteed only when used as indicated in these instructions; therefore they should be kept for future reference. To prevent electrical shock, turn off power supply before carrying out any connection or maintenance operations.*

The following instructions allow you to install a surface mount system configuration with accessories; your installation process may vary.

Surface body




Accessories



**NOTE 1**


The electrical feed needs to be installed first. Please refer to Surface Feed Installation document Y503-12077. Pay attention to the Feed placement as it cannot be installed everywhere, due to the presence of mounting brackets.

Electrical Feed  
Mount Kit




allowable areas for electrical feed in gray

4ft (118cm) Model, viewed from above



8ft (237cm) Model, viewed from above






## STEP 1


Measure and mark the mounting locations depending on your configuration.

4ft (118cm) Model




overall length: 46 <sup>5</sup>/<sub>8</sub>" (1184mm)

8ft (237cm) Model



overall length: 93 <sup>1</sup>/<sub>2</sub>" (2368mm)






bracket can be moved to  
alternate hole to  
accommodate a centered  
power feed

## STEP 2

- 2.1 If mounting over the electrical feed, make sure the wiring is routed properly on top of the body.
- 2.2 Mount the body to the surface at the previously marked locations (hardware not supplied)





Side view





**STEP 3**


Slide in and tighten any linear or angular joiners depending on your system configuration. The joiners do not need to be physically mounted to the wall/ceiling.






**STEP 4**


4.1 Foil tape is supplied in order to ensure there are no light leaks between bodies and joiners. Cut to size, peel off backing and apply to inside portions at each junction.





Horizontal Joiner



Linear Joiner




Vertical Joiner





**STEP 5**

Peel off adhesive gasket on end caps, and slide into body. Tighten the screws to ensure a tight fit.



**STEP 6**

Continue installation of Gear Plate and Optics by referring to the respective documents provided with those components.

